

WINDOWS WELCOME PACK





Welcome to Origin.

Origin is the UK's leading manufacturer of aluminium architectural solutions.

Now award-winning and operating internationally, Origin began in 2002 as a family company dedicated to the design, creation and manufacture of the UK's best quality doors, backed by uncompromising levels of service.

Cousins, Neil Ginger and Victoria Brocklesby, have since worked relentlessly to perfect the design and functionality of bi-folding doors, and to create and maintain the highly respected reputation for quality and service that they have today, while expanding the range to include Entrance Doors, Internal Doors, Sliding Doors and Windows.

As the business has continued to grow and diversify, the foundations of family ethos, pride and ownership in all stages of production firmly remain.

Thank you for choosing Origin.

Neil

NEIL GINGER CEO

Victoria

VICTORIA BROCKLESBY COO



DOWNLOAD YOUR GUARANTEE CERTIFICATE





Opening the Window...

- 1. If locked, unlock the window with the key and then remove key
- 2a. Before turning the handle, press and hold the lock-plate
- **2b.** For right hung windows, turn the handle anti-clockwise 90° from the closed downwards position to the horizontal position
- **2c.** For left hung windows, turn the handle clockwise 90° from the closed vertical position to the horizontal position
- **2d.** For top hung windows, turn the handle anti-clockwise 90° from the closed horizontal position to the vertical upright position
- **3.** Ensure that the handle is fully turned in order to ensure that the lock is fully disengaged
- 4. Push the window frame from either the handle itself or the sash






Reverse the above process to close





Closing the Window...

- 1. Place your hand on the handle and pull the window closed. Ensure that the opening sash is pulled firmly in so that the lock can engage
- **2a.** For right hung windows, turn the handle clockwise 90° from the open horizontal position to the closed downward position
- **2b.** For left hung windows, turn the handle anti-clockwise 90° from the horizontal position to the closed vertical position
- **2c.** For top hung windows, turn the handle clockwise 90° from the open vertical upright position to the closed horizontal position
- **3.** Lock the window if desired by turning the key clockwise in the handle keyhole to the horizontal locked position. Remove key once finished



6. Open window to ensure hook is re-engaged

7. Close the window



Operating the easy clean function...

On side hung windows, those with easy clean hinges can be opened fully and moved across to the centre of the aperture. This allows the outside of the window to be cleaned

- 1. Open window fully
- 2. Locate black button on the hinge marked "PRESS"
- 3. Push the button and slide 1cm away from the corner
- 4. Repeat for the opposing hinge
- **5.** Locate your hand centrally on the window sash and pull to the centre of the window, ensuring the top and the bottom are moving equally
- 6. Clear access is now available to clean the face of the window
- 7. Once the window is clean, close it as normal to reset the hinges in their original position



Routine Care of your Origin Windows...

Powder coated aluminium profile

Use a light, soapy solution (such as a diluted baby bath product) and non-abrasive cloth to wipe dirt from the window frame. Washing up liquid is not recommended, and do not use solvent based cleaning products. Please also refrain from using an abrasive cloth such as a scouring pad as the window frames can be scratched.

If you are in a marine environment, the windows and hardware should be washed down on a weekly basis with fresh water as it is common for harmful deposits to build up.

Seals

Use a light, soapy solution and non-abrasive cloth to gently clean these. Do not use solvent based cleaning products on the seals.







Home Maintenance Log (tick the appropriate action taken on the date)

Date	Cleaning Frames	Lubricating	Cleaning Sash	Initials

origin

If you would like any aspect of the window operation explaining to you, please call or email a member of the team using the details below.

t 0808 168 5816 e enquiry@origin-global.com w origin-global.com





IF SOMETHING'S NOT RIGHT...

Contact your installer in the event of any problem...

We hope your life has been transformed following the installation of your Origin Home.

Rest assured - as you have chosen Origin, you can relax knowing you're in safe hands.

If, however, you encounter any problems, please contact your installer and they will work with us to rectify any difficulties you may be experiencing.













ORIGIN GLOBAL



ORIGIN_GLOBAL

